

UTDCR-2500 Addendum to directions:

- 1) You can use the door magnet that came with the UT-2500 transmitter or for an optional installation, use the optional (included) magnetic contact with 12" leads (and throw out the small magnet that came with the UT-2500).

- 2) If you use the 12" wire leaded contact; on UT-2500, remove the 4 corner screw covers, then remove the 4 screws. Then screw one of the magnetic contact wires to the middle screw (COM) of the green screw strip. The other magnetic contact wire should be screwed down to the screw terminal labeled 'NC'.

- 3) Follow directions included for UT-2500 and WR-2500.

EZ CyberQuest Inc
2300 Bethelview Rd.
Suite 110-181
Cumming, GA 30040-9475

contact@ezcyberquest.com