

## **TPB LR-2500 Addendum to directions:**

- 1) On UT-2500, remove the 4 corner screw covers, then remove the 4 screws.
- 2) Next take the Photobeam Receiver and connect the two conductor wire included. Black wire to {alarm output} (COM) on both photobeam receiver and UT-2500 transmitter, then Red wire to {alarm output} (NC) on photobeam receiver and UT-2500 transmitter.
- 3) Cut only the small round circular DC plug off both of the cords of the separate AC/DC adapters. Hook one of the adapter wires (doesn't matter which) to the 1 & 2 terminals of the Photobeam transmitter and use the other transformer for the Photobeam receiver.
- 4) Make sure bare wires touch each other at their connection points
- 5) Follow directions included for UT-2500, WR-2500, and E-960-D90Q photobeam sensor.

**EZ CyberQuest Inc**  
2300 Bethelview Rd.  
Suite 110-181  
Cumming, GA 30040-9475

[contact@ezcyberquest.com](mailto:contact@ezcyberquest.com)